Características Paneles PIMA, PYRONIX, ADEMCO

Zonas cableadas											
	9	8	4	9	-	9	8	8	8	8	6
Zonas Inalámbricas	ON	16	ON	ON	24+16	16	40	40	24	55	2.2
Expansión de zonas cableadas	9	8 EXPRO	24FP12900	ON	ON	ON	48-4219	48-4219	16-4219	ON	ON
Zonas dobles	ON	ON	4	ON	ON	ON	7	7	ON	ON	ON
Zonas Multiplexadas	ON	ON	ON	ON	ON	ON	ON	ON	ON	25	2.2
Zonas de sabotaje	Q N	2	ON	ON	ON	ON	ON	ON	ON	ON	ON
Códigos de Usuarios	80	16	32	15	8	8	48	48	15	75	75
Código de Intimidación	Q Q	~	1X USUARIO	1X USUARIO	-	1	1	-	-	1	-
Zona de Ilave	ON	SI	ON	ON	ON	ON	ON	NO	ON	ON	ON
Particiones	1	16	4	1	1	1	2	2	2	2	8
Partición Lobby	ON	ON	1	ON	ON	ON	1	1	ON	ON	1
Teclados	4	8	4	4	ON	4	6	6	4	16	16
Teclado Maestro	ON	ON	S	ON	ON	ON	ON	ON	ON	S	S
Salidas auxiliares	2	2+RELY	4	3+RELY	2	ON	2	2	ON	2	2
Expansión de salidas	O _N	8 OUT-	80	O _N	O _N	4-4204	16-4204 O X10	16-4240 O X10	8-4240 O X10	16-4204 O X10	16-4204 O X10
Comunicador	IS	S	S	S	N N	S	S	S	ī5	S	S
Reporte	S	S	ß	S	ß	ß	S	S	Ø	ß	S
Reporte doble	S	S	IS	S	IS	IS	IS	IS	IS	IS	S
4+2 PPS	S	S	oN S	oN O	SI	SI	S	SI	IS	S	IS
4+2 DTMF	SI	IS	No	No	SI	SI	SI	IS	SI	SI	SI
CONTACT ID	SI	SI	SI	IS	SI	IS	IS	IS	IS	SI	SI
PAF	S	IS	ON	ON	ON	ON	ON	ON	ON	ON	ON
Comunicador											
Vía radio Salida para	<u>is</u>	<u>w</u>	ON.	ON N	O N	0	O Z	O N	0 Z	0 Z	ON.
sirena Monitoreo	~	5	-	1	-	_	-	-	1	-	-
de sirena	S	S	IS	IS	ON	ON	S	IS	S	ON	ON
Monitoreo de							i				
línea telefónica Autoarmado	<u>s</u>	<u> </u>	S	S	0 X	O N	<u>N</u>	S	O Z	īs	O N
programable por el usuario final	ıs	S	S	ON	ON.	ON	S	CZ	S	<u>w</u>	<u> </u>